

OVN/MIKROOVN

Ovn funktion

- Tøm ovnen for alt indhold.
- Hvad skal laves? Drejeknap længst til venstre. Luftovn, drejes til venstre så du lander på nummer 5 på drejeknap F.
- Så står tallene og blinker X grader, samt lyser en vifte i en firkant.
- Drejeknap længst til højre, drejer du til ønskede grader.
- Tryk derefter på OK.
- Så blinker timeren på ovnen.
- Så drejer du igen drejeknappen længst til højre rundt til ønsket tid. Længst tid er 90 minutter.
- Tryk derefter på OK igen.
- Til slut trykker du på Firkanten med PLAY symbol på.
- Viser der en tekst med: "DOOR", åben lågen og luk den igen.
- Tryk herefter igen på firkanten med PLAY symbol på.



Mikroovn funktion

- Tag alt det indhold ud som du ikke skal bruge. Den runde skal være i nederst, så pladen kan dreje rundt.
- Sæt indholdet i og tryk PLAY i 30 sekunder
- Ønskes længere tid mikroovn drejes drejeknappen længst til højre op til ønskede tid.
- For at ændre EFFEKT bruges drejeknappen på venstre side F, drej den 1. gang til venstre.
- Derefter drejes drejeknappen længst til højre til ønskede EFFEKT.

OVEN/MICROWAVE

Oven function

- Empty the oven of all contents.
- What needs to be done? Knob furthest to the left. Air oven, turn to the left so that you land on number 5 on knob F.
- Then the numbers stand and flash X degrees, and a fan lights up in a square.
- Knob furthest to the right, you turn to desired degrees.
- Then press OK.
- Then the timer on the oven flashes.
- Then turn the rightmost dial again around at the desired time. The longest time is 90 minutes.
- Then press OK again.
- Finally, press the Square with the PLAY symbol on it.
- Displays a text with: "DOOR", open the door and close it again.
- Then press again on the square with the PLAY symbol on it.



Microwave function

- Remove all the content that you don't need. The round should be at the bottom so that the plate can rotate.
- Insert the contents and press PLAY for 30 seconds.
- If you want a longer microwave time, turn the knob furthest to the right up to the desired time.
- To change the POWER, use the dial on the left side F, turn it 1 time to the left.
- Then turn the rightmost dial to the desired POWER.